




DROP SAFE BOX(ED)

Instruction Manual





A Message to Our Valued Customer


Dear Valued Business Owner,

Thank you for choosing the ["ED" Series] Drop Safe. We understand that you have invested in more than just a secure metal box—you have selected a trusted partner to protect your daily earnings, along with a transparent and efficient system to support your business.

Your decision reflects both your commitment to your company's security and your deep sense of responsibility toward your team and every achievement earned through hard work. We are truly honored by your trust, what you have placed in our care, we will safeguard with integrity and dedication.

Welcome to a simpler, smarter, and more secure way to manage your cash. We are here to support you every step of the way.

Sincerely,
The [Thmosz] Team



IMPORTANT SAFETY INFORMATION

Thank you for choosing ED Safe to store all your important documents and valuables. We hope that this product will help you stay organized and provide you with the peace-of-mind of knowing the things most important to you are protected.


SAFETY INFORMATION

- 01 Before using this device, please read this user manual carefully.
- 02 Understand and follow the safety and operating instructions to avoid potential risks and hazards.
- 03 Keep this manual for future reference. If you hand over this device to someone else, be sure to provide them with this user manual as well.
- 04 Do not leave safe unattended while open. Keep Children Away from safe.
- 05 Always lock and secure the safe when not in use. Store the backup keys in a secret and secure location not in the safe.
- 06 Remember to record the keyhole serial number and order ID of your safe. You will need it for customer service inquiries.
- 07 Never attempt to dismantle the product by yourself. If maintenance is required, please contact us on the website.


IMPORTANT WARNING

- 01 Do not swallow the battery, there is a risk of chemical burns.
- 02 The batteries (battery block or built-in batteries) must not be exposed to excessive heat, such as direct sunlight, fire, or similar conditions.
- 03 If you think that the batteries have been swallowed or entered any part of the body, seek medical attention immediately.
- 04 Keep new and used batteries out of the reach of children.
- 05 If the battery compartment doesn't close properly, stop using the product and keep it out of the reach of children.

01 Packing Accessories



45/52H




2x Key
(Bottom)




1x External
Battery Box



1x Fireproof
Bag




65H




4x Installation
Accessories



1x Manual



65H




2x Key
(Bottom)




1x External
Battery Box



1x Fireproof
Bag



65H



4x Installation
Accessories





2x Key (Top)



1x Manual


Please keep the emergency keys out of the safe

02 Component Introduction




- | | |
|---------------------------------|-------------------------|
| 1. LCD Display screen | 6. Reset Button |
| 2. Digital Keypad | 7. Built-in Lamp |
| 3. Hidden Keyhole | 8. Lock Bolt |
| 4. Knob | 9. External Battery Box |
| 5. Internal Battery Compartment | |


03 Screen Display Identification



Password correct
unlock icon display




Password error or
Keyboard Lock
alarm icon display



The reminder icon is
displayed when the
battery is low


04 The First Opening




1. Remove the emergency cover in the middle of the panel.
2. Insert the emergency key counter-clockwise as shown.
3. Turn the knob to open the door.

CAUTION: Finish operation, pull out the emergency key and keep it in a safe place, PLEASE DO NOT KEEP THE EMERGENCY KEYS IN THE SAFE!

05 Installing The Battery




06 Open The Door With Password



1. Input the preset code 159 and press the "#", the green light will on and you will hear 2 buzzer beep.
2. Turn the knob to open the door.

! CAUTION: The initial password is 159. Confirm with #.

07 Open The Door With External Battery Box




When the battery is dead and you can't find the key, you can plug in the external battery box to charge it and enter the code to turn it on.

! CAUTION: PLEASE DO NOT KEEP THE EXTERNAL BATTERY PACK IN THE SAFE!

08 Set The Code


1. Open the safe and keep it unlock.
2. Press the reset button behind the door, the green light will on and you will hear 2 buzzer beep.
3. Input 3-8 digits new code and press "#" to confirm.
4. The new code has been accepted and stored.




09 Notice

- 01 To lock the safe, manually rotate the knob to secure it and remove the key.
- 02 If you enter the wrong password during the process of entering the password, you can press the " * " key to clear (clear all previous operations) and re-enter.
- 03 If 3 incorrect codes input continuously, the keypad will be locked about 20 seconds; If another 3 incorrect codes input again, then the keypad will be locked for another about 20 seconds, and so on.
- 04 If the battery depletion icon appears on the screen during operation, indicating that the battery is low, please replace the battery as soon as possible.
- 05 If you forgot the code or the batteries are run off, use the emergency key to open the safe as the first opening, and then press the reset button(on the left-side of back of door) to reset the code.
- 06 Any key pressed for 20 seconds, no subsequent key input into the sleep state, the front input cleared.
- 07 The electronic part of the electronic safe will be short-circuited when it encounters liquids, and the product can not be placed in a humid environment. It is easy to cause the risk of circuit back-moistening and failure.


10 Step For Mounting



STEP1



STEP2



STEP3

1. Drill the appropriate size holes for the anchors you are using.
2. Carefully press the anchor into the holes at this time.
3. Mount the safe by running screws from inside of the safe and securing to anchors. Ensure the safe is mounted securely.

